

33155 CAMINO CAPISTRANO • UNIT C • SAN JUAN CAPISTRANO, CA 92675 PHONE: (949) 240-6353 • FAX: (949) 248-5655

NAV-2 VACUUM VALVE V-2

DESCRIPTION

Vacuum Valve NAV-2 is a two piece vacuum assembly manufactured from 6061 T6 aluminum. The base plate can be supplied in aluminum or M1020 steel. The rubber gasket is designed for easy replacement. All commonly used disconnects can be used with NAV-2 valve.

NAV-2

Aluminum base

1/4"MPT

APPLICATIONS

This valve is designed for use with all composite plastic or metal-bond lay ups where vacuum and high pressure, combined with high temperatures, are essential.

DIRECTIONS FOR USE

Place base or valve under vacuum bag. Cut slit in bag approximately 3/4" long. Place pressure plate on outside of bag. Twist lock to base plate.



33155 CAMINO CAPISTRANO • UNIT C • SAN JUAN CAPISTRANO, CA 92675 PHONE: (949) 240-6353 • FAX: (949) 248-5655

NAV-3 VACUUM VALVE V-3

DESCRIPTION

Vacuum valve NAV-3 is manufactured from 6061 T6 Aluminum with a M1020 steel knurled fastening nut and ¼" MPT. This valve incorporates improved features over existing valves.

The 2-34 diameter base has channels fully to the edge of the base eliminating possible seal off and insuring good air evacuation without tipping over during use. The sturdy pressure plate is locked by means of a steel pin and slot to prevent bag twisting. A positive seal can be accomplished with finger tight pressure applied to the steel nut.

All commonly used quick disconnects can be used with NAV-3 valve.

APPLICATIONS

This valve is designed for use with all composite, plastic or metal-bond lay ups, where vacuum and high pressure combined with high temperatures are essential.

DIRECTIONS FOR USE

Place base of valve with silicone rubber gasket under bagging film Cut slit in bagging film and place over valve stem. Cross cut slit approximately 34". Install pressure plate, making sure notch lines up with the pin. Screw down steel nut tightly with finger pressure only.



33155 CAMINO CAPISTRANO • UNIT C • SAN JUAN CAPISTRANO, CA 92675 PHONE: (949) 240-6353 • FAX: (949) 248-5655

OH-50 450° F Material Autoclave Hose

DESCRIPTION

OH-50 hose is a high temperature, silicon rubber over a flexible steel tube assembly with hex male pipe threads on each end.

PHYSICAL PROPERTIES

Withstands

450° F at 200 psi

Long life

Does not have bag-puncturing "whiskers" as braided hoses do.

Maximum temperature:

450° F 200 psi

Maximum pressure: Hose ID:

1/4", 3/8", 3/4" OD

Length:

As required



33155 CAMINO CAPISTRANO • UNIT C • SAN JUAN CAPISTRANO, CA 92675 PHONE: (949) 240-6353 • FAX: (949) 248-5655

QD-14 QUICK DISCONNECT

DESCRIPTION

QD-14 two-way disconnect positively seals both ends of the line when the coupling is disconnected. Spring actuated valves in both the socket and the plug provide an immediate and positive seal.

When connected, a complete seal is effected by the compression of the high temperature o-ring.

PHYSICAL PROPERTIES

O-ring seal 500 degree F
'4" standard pipe threads
Positive seal
Fits both our hose (ACH-1000) and Vacuum valves (V-2 & V-3)
QD-14 Standard cad plated steel
QD-14S Stainless steel



33155 CAMINO CAPISTRANO • UNIT C • SAN JUAN CAPISTRANO, CA 92675 PHONE: (949) 240-6353 • FAX: (949) 248-5655

VACUUM PUMP MODEL 250B REGULATOR WITH GAUGE AND MUFFLER INCLUDED

DESCRIPTION

Compressed Air Consumption (c.f.m.)

Maximum Vacuum (inches HG)

Maximum Airflow at "0" Load (c.f.m.)

Suction Port Connection Dimensions (inches)

Body Dimensions (inches)

7 ½ x 2 ¼ x 3 ½

The vacuum pump that is everything but conventional

All conventional vacuum pumps are driven by electricity.

Most vacuum pumps are driven by an electric motor that created a relatively high sound level and generates undesired heat. These disadvantages are of some significance as the pumps usually run continuously from morning to night. With a great many fast moving parts the service requirements are rather large.

The 250B vacuum pump is driven by compressed air - economical!

Industries using our vacuum pump are spared all the "classical" vacuum pump problems. The 250B pump is driven by compressed air. It is not noisy, does not generate heat, and therefore, the surrounding environment is improved. The workplace is more comfortable and the operation altogether more sensible. The use of compressed air is extremely economical as it is only used when the vacuum is applies. The fast reaction to the compressed air power supply avoids the need for a vacuum pump to be running all the time.